

Installation instructions for **HMI** HOYME Motorized AUTOMATIC FLUE DAMPER - SERIES 'HAC - F' for GAS and OIL Burning Appliances

THIS INSTALLATION SHALL BE SUBJECT TO THE APPROVAL OF THE ENFORCING AUTHORITIES.



Damper profile up to 9" diameter




Damper profile for 10" and over

This **Automatic Flue Damper** saves energy and also protects the heat exchanger while the appliance is in the non-firing mode. The damper stops the escape of warm air up the flue and at times, the reverse, stops cold air from coming down the flue. Cold air not only wastes energy but also puts extra strain on appliance parts. The damper comes with an end switch so that the damper proves to be open before the appliance fires. **It is securely installed in the flue vent close to the appliance and matches the size of the factory built flue.** This damper is power closed and has a return spring to **fail-safe-open**. On some heating appliances, the 24Vac supply turns off during the non-firing cycle or for **OIL** where 'T'-'T' terminals are not identified. An **auxiliary transformer** (24Vac) is then used to keep the damper closed. If the safety circuit is not fuse protected, use the **in-line fuse** and holder supplied. Part **#3152-001**. (See wiring diagram)

For **COMMERCIAL** installations having other than 24Vac circuits, **RELAY ADAPTORS** are available for interfacing this damper to a **250mVdc to 100Vdc or a 120Vac Safety Control System**.

This installation shall be in accordance with: In Canada - CAN/CSA B149 & B139; In the USA - ANSI/NFPA 54, 2006, ANSI Z223.1 and/or local codes including local codes relating to exhaust vent installation. A qualified contractor shall be consulted regarding the installation of this damper.

Specifications:
Motor 24Vac, - 5 Watts, 50/60 Hz.
Relay Coil 0.05 Amps.
Damper Identification having a 10" dia.:
e.g.: **HAC-1041-SPC - F**



*4 - designates a **Belimo** actuator, **spring return** for diameters larger than 9".

AUTOMATIC FLUE VENT DAMPERS are designed to operate for years of trouble free service and are to be checked yearly for proper operation.

ELECTRICAL WIRING shall be done in accordance with the **National Electrical Codes** or with **Local Codes** where they prevail. **Additional wire** shall be of the same size and type as used with existing control circuits. **Wiring thereto** shall be well secured and reasonably remote from any source of heat.

INSTALLER must be a trained, qualified person. Labels and damper operation shall be readily visible when in the installed position.


Note: Before interlocking this damper to a safety control circuit, the heating appliance is to be checked for proper operation, according to its manufacturer's specifications and according to applicable codes.

CONNECTING to 24Vac APPLIANCE CIRCUIT:

- 1) To Terminal strip, use ('W' 'R' 'C') or
- 2) To Gas Valve, use ('TH'; 'TH-TR'; 'TR')

1. Set thermo/aqua-stat (stat) down to the lowest setting and turn off electrical power supply.
2. Connect damper BLUE wire (5) to the 24Vac transformer wire leading to the stat or ('R' on the terminal strip; or 'TH-TR' on the gas valve).
3. Connect damper BROWN wire (3) to transformer common or ('C' on appliance terminal strip or 'TR' on the gas valve).
4. **Test** by turning on the power supply causing the damper to close. Turn off power supply.
5. Remove stat wire connected to ('W' on terminal strip or 'TH' on the gas valve) and connect this stat wire to the damper BLACK wire (1) using a wire nut. *See diagram regarding fuse protection.
6. Connect damper RED wire (2) back to ('W' on the terminal strip or 'TH' on the gas valve).
7. Turn on power supply and damper will close. Turn stat to call for heat. Damper will open and appliance will operate normally.
8. Sequence the appliance through at least three normal cycles to confirm proper operation.

SCHEMATIC WIRING DIAGRAM OF FLUE DAMPER and APPLIANCE TRANSFORMER.



Note: This marking is also on label to be affixed adjacent to appliance wiring diagram.

Δ Typical location for 24Vac limit control when used in appliance circuit.

- Circuit to be grounded if not previously grounded. Affix appropriate labels and follow instructions and warnings on each label.
- Always conduct a thorough check-out after installation is complete.
- Damper type is **Power Close** and **Spring Open**.
Note: Test/Run switch on the damper is to be in the up 'Run' position.

AUXILIARY TRANSFORMER Connected to:


- 1) Oil, use ('T' 'T') or
 - 2) Gas Valve, use ('TH'; 'TH-TR') or
 - 3) Terminal strip, use ('W' 'R' 'C')
- (See Auxiliary Wiring Diagram on page 3).

Note: Test/Run switch on the damper is to be up in the 'Run' position.

INSTRUCTION #9 explains proper phasing of 24 Vac transformer.

1. Turn stat to lowest setting.
2. Turn off electrical power supply. Install auxiliary transformer connected to appliance power supply.
3. Remove one stat wire from appliance ('T'; or 'TH-TR'; or 'R') and by using a wire nut, join four wires: Stat wire, Damper BLUE (5) wire, 24Vac auxiliary transformer wire and a 6" stub wire. Connect stub wire back to appliance stat terminal.
4. Connect Damper BROWN (3) wire to remaining 24Vac auxiliary transformer wire.
5. Test by turning on power supply. Damper will close. Turn off power supply.
6. Remove other stat wire from remaining appliance ('T'; or 'TH'; or 'W') and connect it to Damper BLACK (1) wire with wire nut supplied. **NOTE:** In-line fuse to be connected here if circuit has not been previously protected.
7. Connect Damper RED (2) wire back to appliance stat terminal ('T'; or 'TH'; or 'W').
8. Turn on power supply to close Damper. If no action, interchange auxiliary transformer wires and retest.
9. How to **PHASE TRANSFORMERS:** Jumper Damper (1) BLACK wire momentarily to Damper (2) RED wire. If Damper opens, an out-of-phase situation is indicated. Correct by interchanging auxiliary 24Vac transformer wires and retest.
10. Turn stat to call for heat. Damper will open and heating appliance will operate normally.

SCHEMATIC WIRING DIAGRAM OF FLUE DAMPER CONNECTED TO A 24Vac SAFETY CIRCUIT AND AN AUXILIARY TRANSFORMER.



Note: This marking is also on label to be affixed adjacent to appliance wiring diagram.

- * A 3 amp fuse and fuse holder part #3152-001 is included if required.
- Affix appropriate labels and follow instructions and warnings on each label.
- Always conduct a thorough check-out after installation is complete.
- Follow all applicable Codes.
- Sequence the appliance through at least three normal cycles to confirm proper operation.

General Information: The damper uses power to close when the appliance is not firing and cuts the power to the damper when the appliance is firing. This eliminates the damper overloading the appliance transformer during the firing cycle.

General Wiring Information:

Two wires from the damper motor are connected to the appliance transformer and two wires from the damper end switch are connected in series with the controlled stat wire.

TROUBLESHOOTING PROCEDURE:

A. Condition: **Damper does not open** or fully open when the stat asks for heat.

Cause: This indicates

- 1) Signal is not getting through** from the stat to the damper.
- 2) Mechanical friction** with motor, motor gears or rotor spring.
- 3) Broken damper return spring.**

Procedure: **1a)** Check in-line fuse (if used) between stat wire and damper black wire #1.

1b) Remove cover and with a jumper wire join terminals 1 & 5. If damper opens, a faulty stat is suspected. **1c)** Turn Test/Run Switch to the 'Test' position and jumper terminals 1 & 2. If appliance does not fire, a faulty stat or stat circuit is confirmed. **2a)** If the damper has not been activated for a period of time, (e.g. summer months) the motor gears, being under continual pressure, might stick. If condition continues, replace motor. **2b)** Motor gears wear with age causing increased friction which prevents the damper from opening freely. Replace motor.

2c) Broken spring in the motor rotor. Remove broken spring with long nose pliers. The damper will continue to operate normally without the broken rotor spring. **3)** Remove damper spring plate and replace with a new spring and plate.

B. Condition: **Damper does not close** after appliance completes its firing cycle.

Cause: Indicates

- 1) Test/Run switch is not** in the 'run' position
- 2) A faulty relay**
- 3) No power supply**
- 4) A Faulty motor.**

Procedure: **1)** Check Test/Run switch to be in the up 'RUN' position.

2) Remove control body cover and use a jumper between terminals 3 & 4. If damper closes, a faulty relay is indicated.

3) Check power supply to terminals 3 & 5.

4) Connect power supply to terminals 4 & 5. No response indicates a faulty motor.

